


Hydraulic Chassis



Pos.	Leckey Code	Description	Qty
1	151-3838	Chassis Assembly	1
2	IA31	5" Castor	2
3	IA62	5" Caster-Directional Lock	2
4	151-3839	Hi-Lo Assembly	1
5	133-2100	Tilt Gas Shock	1
6	161-1047	Interface	1
7	133-2102	Pedal	1
8	133-2098	Hydraulic Actuator	1
9	161-1011	Cable	1
10	161-1010	Release Lever	1