


## Power Chassis



Pos.	Leckey Code	Description	Qty
1	151-3838	Chassis Assembly	1
2	IA31	5" Castor	2
3	IA62	5" Caster-Directional Lock	2
4	151-3839	Hi-Lo Assembly	1
5	133-2100	Tilt gas shock	1
6	161-1047	Interface	1
7	161-1054	Power Actuator	1
8	161-1055	Control Box & Battery (Charger Included)	1
9	161-1056	Handset	1
10	161-1011	Cable	1
11	161-1010	Release Lever	1