


Squiggles Stander Easel Chassis



Pos.	Leckey Code	Description	Qty
1	118-765	Easel Chassis	1
2	SF19	Locking Key (M8 X 16)	2
3	SF53	Round Tube Insert	2
4	SC62	Plastic C'feet	5
5	102-1232	Pedal Rubber Pad (Trim)	1
6	SF61	Square Ribbed Insert	2